


Instructions for:

# X-Ceptional Banner Display



## STEP 1

Unzip and remove from case.



## STEP 4

Once extended gently tighten knobs to hold arm in place (do not over tighten). Repeat with support pole in back to set frame at desired angle.



## STEP 2

Fold out all four arms gently pressing them into their permanent positions. You should feel a slight snap when in proper position. Repeat with the support pole in the back of the unit.



## STEP 5

Stand frame up. One can adjust the tilt by moving the back support leg forward or backward.




## STEP 3

On banner arms loosen each of the four knobs very slightly as this allows one to extend them fully. Slide banner arms to full extension. Make sure pointed knobs on the end of the arms point FORWARD.



## STEP 6

Now you are ready to add the banner. Simply hook the grommet holes onto the four pointed knobs at the edges of the display arms. The stand will have a slight "Bow Effect" which keeps the banner smooth and taut.



**Graphic Size:**  
45"-72" H x 20"-35" W