

Instructions for:

Everyday Banner Display




STEP 1

Remove the contents of the box. You will find a large square tube, a small square tube, the top dowel holder, the bottom dowel holder, the base plate and a package of hardware.




STEP 2

Before you attach the bottom base plate, slide the bottom dowel holder, open side up, over the bottom of the large square tube and tighten with the thumb-screw. The smooth end of the large square tube is the bottom. The top end has a wing nut receptor.




STEP 3

Insert the raised area of the base plate into this unit and secure by inserting the silver screw up through the bottom of the base plate. Tighten the screw with the included Allen wrench.



STEP 4

Insert the bottom of the small square tube into the top of the large square tube. The bottom of the small tube has the open end.



STEP 5

BSDBK BSDTTBK

Attach the top dowel holder to the top of the small tube with the remaining screw. Tighten the screw with the included Allen wrench.

